



...leaves you with a smile

OWNER'S MANUAL

42" TOWER FAN WITH REMOTE CONTROL

MODEL: BET-42EB



READ AND SAVE THESE INSTRUCTIONS

Attention: Pictures in the IM are for reference only.

CAUTION

Read Rules for Safe Operation and Instructions Carefully.

WARNING


1. If the supply cord is damaged, it must be replaced by manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
2. To protect against the risk of electrical shock, do not immerse the unit, cord or plug in water or other liquid.
3. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
4. When the appliance is not in use and before cleaning, unplug the appliance from the outlet.
5. Keep electrical appliances out of reach from Children or infirm persons. Do not let them use the appliances without supervision.
6. When the fan was assembled, the rotor blade guard shall not be taken off anymore
 - Prior cleaning unplug the fan.
 - The rotor guard shall not be disassembled/opened to clean the rotor blades.
 - Wipe the fan enclosure and rotor blade guard with a slightly damp cloth.

RULES FOR SAFE OPERATION




1. Never insert fingers, pencils, or any other object through the grille when fan is running.
2. Disconnect fan when moving from one location to another.
3. Be sure fan is on a stable surface when operating to avoid overturning.
4. DO NOT use fan in window, rain may create electrical hazard.
5. Household use only.

PARTS IDENTIFICATION:




CONTROL PANEL AND REMOTE CONTROL:

NOTE: Always put the plug into the socket first. The product's power lamp will illuminate, indicating that the product is in standby.



REMOTE CONTROL:

NOTE: The functions and operations are the same as the control panel
The remote control uses one button cells, model No. CR2025 (3V). We recommend the use of Lithium type battery for longer use.




Note: Please follow battery disposal instruction on battery packaging, or contact your local councils for safely disposal of batteries.

ASSEMBLY:

- Step 1: Make sure the four holes of the front and back base are in a straight alignment. Position the holes of back base insert into the cylinder of front base.
- Step 2: Take out the power cord from the center of base
- Step 3: The assembled base will have four screw holes which fix the base to

the body. Use 4 tapping screws to fix the body and base tightly. Finally, take the power cord into the cable line hole.

Step 4: Put the Power Cord Storage Rack into the correct position of the back side of the body



OPERATING INSTRUCTIONS:

1. Insert the plug into a 220-240V~50Hz outlet. A beep will sound, and the current temperature will display.

2. Touch the  POWER button first time use the fan will trun on speed 1.

3. Touch the  SPEED button of the control panel repeatedly to select the 1-3 fan speeds. Touch the Remote control of SPEED button, to setting the SPEED function + - to INCREASE or DECREASE the speed from 1-3 speeds.

4. The timer can be set to turn off the fan anytime within 1-12 hours. Touch the

control panel , TIMER button repeatedly to select the time (01H, 02H, 03H etc.). The timer icon will display when the timer mode is in use. The display will revert to showing the current temperature once the timer is set. Press the TIMER button on the remote control, to set the TIMER function + - to INCREASE or DECREASE the time from 1-12 hour settings

5. Touch the  MODE button to select one of the following options:

- Press once to select the AI mode. The display icon will light up . In AI mode, the air speed will adjust automatically based on the set temperature
- Press twice to select the Natural model. The display icon will light up 
- Press thrice to select the Sleep mode. The display icon will light up 
- Press four times select the Normal mode, the display screen will not light up at all

NOTE: You can only select the speed settings (1-3) when in Normal, Natural or Sleep mode

6. Touch the  OSCILLATION button to swing the fan up to 70 degrees. The oscillation icon will turn on. Touch it again to stop the fan oscillating. The oscillation icon will turn off

7. Touch the  Led Night Light Button to turn off and on the LED night light

8. When you are not using the fan, touch the  POWER button to turn it off and unplug the appliance to disconnect it completely from the power supply.

OPERATING INSTRUCTION

1. Speed is controlled by pressing the piano switch.
0---Off 1---Low 2---Medium 3---High
2. To make/stop the fan head oscillate. Push down/pull up the clutch knob.
3. The airflow can be adjusted upward or downward by loosening the tilt adjustment knob and adjusted the vertical angle as desired. Retighten the knob securely.
4. The height of the fan can be adjusted by loosening the height adjustment ring, carefully raising or lowering the fan and firmly re-tightening the height adjustment ring.

MAINTENANCE INSTRUCTION

The fan requires little maintenance. Do not try to fix it by yourself. Refer it to qualified service personnel if service is needed.

1. Before cleaning and assembling, fan must be unplugged.
2. To ensure adequate air circulation to the motor, keep vents at the rear of the motor free of dust. Do not disassemble the fan to remove dust.
3. Please wipe the exterior parts with a soft cloth soaking a mild detergent.
4. Do not use any abrasive detergent or solvents to avoid scratching the surface.
Do not use any of the following as a cleaner: gasoline, thinner.
5. Do not allow water or any other liquid into the motor housing or interior parts.

CLEANING

1. Be sure to unplug from the electrical supply source before cleaning.
2. Plastic parts should be cleaned with a soft cloth moisten with mild soap.
Thoroughly remove soap film with dry cloth.

Environment Friendly Disposal



You can help protect environment
please remember to respect the local regulations
hand in the non-working electrical equipments to
an appropriate waste disposal center

BRÜHM products are intended for household use only

BRÜHM has policy of continuous improvement in
product quality and design. The company, therefore
reserves the right to change the specification of its model at
any time.